

Stecker Scanner-Platine Platz 5

1a	Gnd	1c	Gnd
2a	Gnd	2c	Gnd
3a	DA 3	3c	DA2
4a	DA1	4c	DA0
5a	PWM2	5c	PWM3
6a	PWM4	6c	PWM5
7a	PWM6	7c	PWM7
8a	SDA	8c	SCL
9a	D41	9c	D40
10a		10c	
11a		11c	
12a	+45V, Ausgang !	12c	+45V, Ausgang !
13a	+45V, Ausgang !	13c	+45V, Ausgang !
14a	-45V, Ausgang !	14c	-45V, Ausgang !
15a	-45V, Ausgang !	15c	-45V, Ausgang !
16a	D45	16c	D44
17a	D47	17c	D46
18a	D49	18c	D48
19a	AD6	19c	AD7
20a	AD4	20c	AD5
21a	AD2	21c	AD3
22a	AD0	22c	AD1
23a	+5V	23c	+5V
24a	+5V	24c	+5V
25a	+10V unstab.	25c	+10V unstab.
26a	+10V unstab.	26c	+10V unstab.
27a	-15V	27c	-15V
28a	-15V	28c	-15V
29a	+15V	29c	+15V
30a	+15V	30c	+15V
31a	Gnd	31c	Gnd
32a	Gnd	32c	Gnd

SubD Stecker female 9 pol. Strom Scanner ~+- 500mA

1	I Chanel 0 -	6	
2	I Chanel 1 -	7	
3	I Chanel 1 +	8	
4	I Chanel 0 -	9	
5	Gnd		

SubD Stecker male 9 pol. Spannung Scanner ~+-40V

1	Gnd	6	
2	U Chanel 0 -	7	
3	U Chanel 1 -	8	
4	U Channel 1 +	9	
5	U Chanel 0 +		